

DISCO STRINGS

For KRONOS



By

Keyboard Waves

Make Your Keyboard Sound Better

OWNER'S MANUAL

INTRODUCTION

Thank you for purchasing the Keyboard Waves «Disco Strings» library for the Korg Kronos synthesizer/workstation. This library consists of 10 new User Voices, utilizing over 156 MB of new disco strings samples. Instructions for loading are included in this manual.

Product Description

Disco Strings library programmed by Keyboard Waves

KRONOS FORMAT

- * Format: .KSC ; .PCG ; .KGE
- * Name: Disco Strings 1_3.KSC
- * Size: 156 MB
- * Voices: 10 User Voices
- * Bank loads to: User Bank G

The Voices Descriptions USER G BANK

Number	Name	Description
U-G000	Disco Strings	Mainpatch of Disco Strings
U-G001	Disco Strings Without Falls	No Falls Samples on Top Velocity
U-G002	Disco Strings Falls	Only Falls Samples
U-G003	Attack Strings	Fast Attack Strings
U-G004	Disco Strings Octave	+ 1oct Strings Osc
U-G005	Disco Strings Octave Without Falls	+ 1oct Strings Osc without Falls Samples
U-G006	Disco Strings Falls Octave	+ 1oct Falls Samples
U-G007	Strings Pad	Long Attack & Release for Pad Comping
U-G008	Disco Strings Vintage	Vinyl FX add
U-G009	Tremolo Strings	Tremolo to the max

CONTROLLERS

CC Number	Name	Description
1	MW (Modulation Wheel)	Tremolo

HOW TO LOAD THE SOUNDS

WARNING – BACK UP YOUR DATA FIRST

BEFORE YOU LOAD “Disco Strings”, MAKE SURE YOU HAVE BACKED UP (SAVED) ANY DATA IN YOUR KRONOS THAT YOU MAY WANT TO KEEP.

FROM THE DOWNLOADED ZIP FILE TO USB DEVICE

- 1 - Download Zip file & decompress the Disco Strings Kronos 1.3.zip file.
- 2 - Insert your USB device into your computer’s available USB slot. Its’ icon should appear on your desktop.
- 3 - If it isn’t already open, navigate to the “Disco Strings” folder and double-click on it to open it.
- 4 - Copy all the files called “Disco Strings” to your USB device’s icon (by either dragging the file directly to the icon, or going to your file menu and choosing “Copy” and “To” and selecting the USB device as your destination).
- 5 - When the files had copied completely to your USB device, properly eject the USB device and insert it in the slot labeled “A” on the rear panel of your Kronos.
- 6 - Copy the files into the Kronos Hard disk.
- 7 - Select the file on preload.
- 8 - Load the KSC file and check “on” for load PGM too.
- 9 - The Presets are located in user G..

NOTE: When you power off your Kronos, the samples loaded will be lost if you don’t save file into Kronos Hard Disk

=====

The data and programming are owned by Keyboard Waves.
When you purchase these sounds you are purchasing a license to use them in your music productions as you see fit. Reselling, duplicating or uploading of Keyboard Waves products to any Internet BBS is prohibited and illegal.
Copyright ©2017 Keyboard Waves

=====