

# ***DISCO STRINGS***

For **NORD** Keyboards



By

## ***Keyboard Waves***

Make Your Keyboard Sound Better

## **OWNER'S MANUAL**

## INTRODUCTION

Thank you for purchasing the Keyboard Waves «Disco Strings» library for the Nord Stage 2 & Nord Keyboards synthesizers. This library consists of 3 nsmf Files For Nord Sample Library :

1. Disco Falls
2. Disco Strings
3. Disco Tremolo

New User Voices, utilizing over 31 Mo of new disco strings samples. Instructions for loading are included in this manual.

Disco Strings resampled from the SPDIF output of Motif XF. The files were edited and looped (4 secs) with Nord Sample Editor.

## NSMP Files Compatible Products :

1. Nord Stage 2 EX v1.00+
2. Nord Stage 2 v1.00+
3. Nord Piano 2 v1.00+
4. Nord Electro 5 v1.00+
5. Nord Electro 4 v1.00+
6. Nord Electro 3 v1.16+
7. Nord Wave v2.02+

## Product Description

*Disco Strings library programmed by Keyboard Waves*

## NORD FORMAT :

- \* Samples Format: .nsmf
- \* Name: DiscoFalls.nsmf; DiscoStrings.nsmf; DiscoTremolo.nsmf.
- \* Size: 32MB.
- \* Voices Format: 15 User Voices (.ns2p) for Nord Stage 2.
- \* Voices are transferred with Nord Sound Manager via USB.

## The Voices Descriptions

| Number | Name             | Description                                  |
|--------|------------------|--|
| 1      | Disco Strings AB | Disco Strings = Panel A / Falls = Panel B    |
| 2      | Disco Strings MW | Switch between Panel A / B (Falls) with MW   |
| 3      | Disco Falls      | Only Falls                                   |
| 4      | Disco Octaves    | 2 Panels A & B +1oct                         |
| 5      | Falls Octaves    | 2 Panels with falls samples A & B w +1oct    |
| 6      | Disco Tremolo AB | Disco Strings = Panel A / Tremolo = Panel B  |
| 7      | Disco Tremolo MW | Switch between Panel A / B (Tremolo) with MW |
| 8      | Disco Trem Oct   | 2 Panels Tremolo A & B +1oct                 |
| 9      | Disco Attack     | Short Attack                                 |
| 10     | Disco RomanticMW | Long Attack & Release for Piano Pad          |
| 11     | Disco Kavinsky   | Disco Strings with Arpeggiator               |
| 12     | Disco Pad MW     | Strings Pad                                  |
| 13     | Disco Pad 2 MW   | Strings Pad 2                                |
| 14     | Disco FX MW      | Disco Strings FX controlled via MW           |
| 15     | Disco Ring MW    | Disco Strings with Rig Modular FX            |

# HOW TO LOAD THE SOUNDS

## WARNING – BACK UP YOUR DATA FIRST

BEFORE YOU LOAD “Disco Strings”, MAKE SURE YOU HAVE BACKED UP (SAVED) ANY DATA OF YOUR NORD KEYBOARD THAT YOU MAY WANT TO KEEP.

### FROM THE DOWNLOADED ZIP FILE TO THE NORD MANAGER TRANSFER.

The desired sounds are transferred to your Nord Sample Library compatible instrument with the simple to use Nord Sound Manager.

1. Download the Zip file to your computer and decompress it.
2. Open [Nord Sound Manager](#).
3. Adding new sounds to your instrument is simply a matter of connecting your instrument via USB,
4. Drag-and-drop the Nord files into the application window. The files are automatically transferred to you Nord instrument and has an intelligent Download Queue functionality for transferring many sounds at a time
5. After transfers, Load a patch & Enjoy.

=====

The data and programming are owned by Keyboard Waves.  
When you purchase these sounds you are purchasing a license to use them in your music productions as you see fit. Reselling, duplicating or uploading of Keyboard Waves products to any

=====

Internet BBS is prohibited and illegal.  
Copyright ©2017 Keyboard Waves